

HORN-HIGH PITCH HR100
Two wire installation instructions
(See below for single wire instructions)

1. Cut the existing connector or connectors off of the wires running to the horn and install female blade connectors. (If your current harness already has female blade connectors, skip this step.)
2. Install the black connector supplied onto the new horn making sure the latches on the black connector snap into place on the new horn.
3. Install the bracket using the 6mm nut provided onto the 6 mm stud on top of the horn
4. Connect the wires from the wire harness to the connectors on the horn. (The horn is not polarity conscious.)

Single wire installation

1. Cut the existing connector off of the wire running to the horn and install a female blade connector on the wire. (If your current harness already has a female blade connector, skip this step.)
2. Install the black connector supplied onto the new horn making sure the latches on the black connector snap into place on the new horn.
3. Plug the jumper wire supplied in the kit into one of the blades on the connector on the horn and put the other end of the jumper wire on the 6-mm stud on top of the horn.
4. Install the bracket using the 6mm nut provided onto the 6mm stud on top of the horn. Mount the horn and bracket assembly to a grounded portion of the vehicle.
5. Connect the wire from your vehicle to the other blade of the connector on the horn.